

# Frog mineral System

## Water balance guidelines:

- Free Chlorine                    0.5-1.0
- Calcium hardness            200-400
- Alkalinity                        100-150
- pH level                         7.2-7.6
- Stabilizer                        30-50

Keep pump and filter running 24hrs a day and seven days a week.

## Start-up

1. Balance Water
2. Add Start-up kit (Premix each chemical separately and add 15 minutes apart)
  - 2lbs Turbo Shock
  - 2 containers Algistat
  - 1 container Metal Control Agent
3. Add Clarifier if needed
4. Add Mineral Pac to reservoir
5. Add Frog ALL-OUT algaecide (90 day supply) Run for 2-6 hours
  - 1qt. up to 15,000 gallons
  - 2qts. per 17,500-30,000 gallons
6. Test stabilizer, add if necessary
7. Add Frog chlorine TORPEDO PAC

## Weekly

1. Balance water
2. Shock                            Add Chemicals 15min apart
  - \*\*Turbo Shock
  - 1lb per 10,000 gallons
3. Clarifier
  - \*\*Natural Chemistry 'Clear'
  - 2oz. per 10,000 gallons

## Remember

- a. Replace mineral Pac each season
- b. Algaecide ~ ~ replace every 90 days
  - Frog ALL-OUT ALGAECIDE
- c. Chlorine TORPEDO Pac
  - Check every 2-3 weeks

Monday	Tuesday	Wednesday	<u>Thursday</u>	Friday	Saturday	<u>Sunday</u>
			Test & Balance Water		Enjoy the Pool!!	Test & Balance Water. ♦ Shock ♦ Clarifier

Replace:    --TORPEDO Pac (2-3 Weeks)    --Mineral Pac (Every Season)  
               --ALL-OUT Algaecide (90 days)